


# SERVICE MANUAL

# BG-3S CHASSIS

<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>	<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>
KV-2199XDK	RM-952	ME	SCC-U30J-A				



TRINITRON® COLOR TV  
**SONY®**

## SPECIFICATIONS

		Note
<b>Power requirements</b>	110-240 V AC, 50/60 Hz	
<b>Power consumption (W)</b>	Indicated on the rear of the TV	
<b>Television system</b>	B/G, D/K	
<b>Color system</b>	PAL, PAL 60, SECAM, NTSC4.43, NTSC3.58 (AV IN)	
<b>Channel coverage</b>		
<b>B/G</b>	VHF: E2 to E12 / UHF: E21 to E69 / CATV: S01 to S03, S1 to S41	
<b>D/K</b>	VHF: C1 to C12, R1 to R12 / UHF: C13 to C57, R21 to R60 / CATV: S01 to S03, S1 to S41, Z1 to Z39	
<b>⏏ (Antenna)</b>	75-ohm external terminal	
<b>Audio output</b>	5W + 5W	
<b>Number of terminal</b>		
📺 <b>(Video)</b>	Input: 2    Output: 1	Phono jacks; 1 V <sub>P-P</sub> , 75 ohms
🎵 <b>(Audio)</b>	Input: 2    Output: 1	Phono jacks; 500 mVrms
🎧 <b>(Earphone)</b>	Output: 1	Minijack
<b>Picture tube</b>	21 inch	
<b>Tube size (cm)</b>	54	Measured diagonally
<b>Screen size (cm)</b>	51	Measured diagonally
<b>Dimension (w/h/d, mm)</b>	640 × 456 × 495	
<b>Mass (kg)</b>	27	

Design and specifications are subject to change without notice.

### CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

### SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK ⚠ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
	<b>SELF DIAGNOSIS FUNCTION .....</b>	<b>4</b>			
<b>1. GENERAL .....</b>		<b>8</b>	<b>5. DIAGRAMS</b>		
<b>2. DISASSEMBLY</b>			5-1. Block Diagram .....		35
2-1. Rear Cover Removal .....		19	5-2. Frame Schematic Diagram .....		38
2-2. Chassis Assy Removal .....		19	5-3. Circuit Boards Location .....		40
2-3. F Bracket Removal .....		19	5-4. Schematic Diagrams and Printed Wiring Boards ...		41
2-4. Service Position .....		19	(1) Schematic Diagram of A (1/2) Board .....		43
2-5. Replacement of Parts .....		20	(2) Schematic Diagram of A (2/2) Board .....		46
2-5-1. Replacement of Control Button .....		20	(3) Schematic Diagrams of C5, F, V1 and VM1 Boards ..		52
2-5-2. Replacement of Light Guide .....		20	5-5. Semiconductors .....		59
2-6. Terminal Bracket Removal .....		20			
2-7. Degauss Coil Removal .....		20	<b>6. EXPLODED VIEW</b>		
2-8. Picture Tube Removal .....		21	6-1. Chassis .....		61
<b>3. SET-UP ADJUSTMENTS</b>			<b>7. ELECTRICAL PARTS LIST .....</b>		<b>63</b>
3-1. Beam Landing .....		22			
3-2. Convergence .....		23			
3-3. Focus Adjustment .....		25			
3-4. G2 (Screen) and White Balance Adjustments .....		25			
<b>4. CIRCUIT ADJUSTMENT</b>					
4-1. Adjustments with Commander .....		26			
4-2. Adjustment Method .....		27			
4-3. Picture Quality Adjustments .....		32			
4-4. A Board Adjustment After IC003 (Memory)					
Replacement .....		32			
4-5. Picture Distortion Adjustment .....		33			

## SELF DIAGNOSTIC FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the STANDBY/TIMER lamp will automatically begin to flash.

The number of times the lamp flashes translates to a probable source of the problem. A definition of the STANDBY/TIMER lamp flash indicators is listed in the instruction manual for the user's knowledge and reference. If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

### 1. DIAGNOSTIC TEST INDICATORS

When an errors occurs, the STANDBY/TIMER lamp will flash a set number of times to indicate the possible cause of the problem. If there is more than one error, the lamp will identify the first of the problem areas.

Result for all of the following diagnostic items are displayed on screen. No error has occurred if the screen displays a "0".



Diagnostic Item Description	No. of times STANDBY/TIMER lamp flashes	Self-diagnostic display/Diagnostic result	Probable Cause Location	Detected Symptoms
• Power does not turn on	Does not light	—	<ul style="list-style-type: none"> <li>• Power cord is not plugged in.</li> <li>• Fuse is burned out F4601 (F)</li> </ul>	<ul style="list-style-type: none"> <li>• Power does not come on.</li> <li>• No power is supplied to the TV.</li> <li>• AC power supply is faulty.</li> </ul>
<ul style="list-style-type: none"> <li>• +B overcurrent (OCP) or overvoltage (OVP)</li> <li>• Vertical deflection stopped</li> <li>• Horizontal deflection overdrive</li> </ul>	2 times	002:000 or 002:001~255 003:001~255 004:001~255 at the same time	<ul style="list-style-type: none"> <li>• H.OUT Q511 is shorted. (A board)</li> <li>• IC701 is shorted. (C3 board)</li> <li>• -13V is not supplied. (A board)</li> <li>• IC 503 faulty (A board)</li> </ul>	<ul style="list-style-type: none"> <li>• Power does not come on.</li> <li>• Load on power line is shorted.</li> <li>• Has entered standby state after horizontal raster.</li> <li>• Vertical deflection pulse is stopped.</li> <li>• Power line is shorted or power supply is stopped.</li> </ul>
• White balance failure (no PICTURE)	5 times	005:000 or 005:001~225	<ul style="list-style-type: none"> <li>• G2 is improperly adjusted. (Note 2)</li> <li>• CRT problem.</li> <li>• Video OUT IC701 is faulty. (C3 board)</li> <li>• IC301 is faulty. (A board)</li> <li>• No connection A board to C3 board.</li> </ul>	<ul style="list-style-type: none"> <li>• No raster is generated.</li> <li>• CRT cathode current detection reference pulse output is small.</li> </ul>
• Micro reset	—	101:00 or 101:001~225	<ul style="list-style-type: none"> <li>• Discharge CRT (C3 Board)</li> <li>• Static discharge</li> <li>• External noise</li> </ul>	<ul style="list-style-type: none"> <li>• Power is shut down shortly, after this return back to normal.</li> <li>• Detect Micro latch up.</li> </ul>

Note 1: If a + B overcurrent is detected, stoppage of the vertical deflection is detected simultaneously.

The symptom that is diagnosed first by the microcontroller is displayed on the screen.

Note 2: Refer to screen (G2) Adjustment in section 3-4 of this manual.

## 2. DISPLAY OF STANDBY/TIMER LIGHT FLASH COUNT



<u>Diagnostic Item</u>	<u>Flash Count*</u>
+B overcurrent/overvoltage Vertical deflection stopped	2 times
White balance failure	5 times

\* One flash count is not used for self-diagnostic.

## 3. STOPPING THE STANDBY/TIMER FLASH

Turn off the power switch on the TV main unit or unplug the power cord from the outlet to stop the STANDBY/TIMER lamp from flashing.

4. SELF-DIAGNOSTIC SCREEN DISPLAY

For errors with symptoms such as “power sometimes shuts off” or “screen sometimes goes out” that cannot be confirmed, it is possible to bring up past occurrences of failure for confirmation on the screen:


[To Bring Up Screen Test]

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

Screen display ➡ channel 5 ➡ Sound volume - ➡ Power ON  
↑

Note that this differs from entering the service mode (mode volume +).

Self-Diagnosis screen display



5. HANDLING OF SELF-DIAGNOSTIC SCREEN DISPLAY

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen during repairs. When you have completed the repairs, clear the result display to “0”.

Unless the result display is cleared to “0”, the self-diagnostic function will not be able to detect subsequent faults after completion of the repairs.

[Clearing the result display]


To clear the result display to “0”, press buttons on the remote commander sequentially as shown below when the diagnostic screen is being displayed.

Channel 8 ➡ 0

[Quitting Self-diagnostic screen]

To quit the entire self-diagnostic screen, turn off the power switch on the remote commander or the main unit.

## 6. SELF-DIAGNOSTIC CIRCUIT

**+B overcurrent (OCP)**

Occurs when an overcurrent on the +B(135) line is detected by Q604. If Q604 go to ON and the voltage to pin 18 of IC301 should go down when V.SYNC is more than seven verticals in a period, the unit will automatically turn off.

**Vertical deflection stopped**

Occurs when an absence of the vertical deflection pulse is detected by Q509 and IC001 shut down the power supply.

**Vertical deflection overcurrent**

Occurs when an overcurrent on V drive line is detected by Q507. Power supply will be shut down when detect this by IC001.

**White balance failure**

If the RGB levels\* do not balance or become low level within 5 seconds, this error will be detected by IC301. TV will stay on, but there will be no picture.











\* (Refers to the RGB levels of the AKB detection Ref pulse that detects IK.)

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

## SECTION 1 GENERAL

### WARNING

- Dangerously high voltages are present inside the TV.
- Operate the TV only between 110 – 240 V AC.

 <p>Do not open the cabinet and the rear cover of the TV. Refer servicing to qualified personnel.</p>	 <p>Install the TV in a stable position. Do not allow children to climb onto it.</p>
 <p>To prevent fire or shock hazard, do not expose the TV to rain or moisture.</p>	 <p>Do not operate the TV if any liquid or solid object falls into it. Have it checked immediately by qualified personnel only.</p>
 <p>Do not install the TV in a confined space, such as a bookcase or built-in cabinet. Do not block the ventilation openings of the TV.</p>	 <p>Clean the TV with a dry and soft cloth. Do not use benzene, thinner, or any other chemicals to clean the TV. Do not scratch the picture tube.</p>
 <p>Do not pull the power cord to disconnect the TV. Pull it out by the plug.</p>	 <p>Do not plug in too many appliances to the same power socket. Do not damage the power cord.</p>
 <p>Disconnect the power cord during lightning storms or if you are not going to use the TV for several days.</p>	 <p>Do not install the TV in hot, humid or excessively dusty places.</p>


### Using Your New TV

## Getting Started

### Step 1


#### Connect the antenna

If you wish to connect a VCR, see the “Connecting a VCR” diagram below.






#### Connecting a VCR

To watch the video, press   (see page 12).



#### Notes


- If you connect a stereo VCR, connect the yellow plug to  (the yellow jack) and the white plug to  (the black jack).
- If you connect a VCR to the  (antenna) terminal, preset the signal output from the VCR to the program number 0 on the TV.
- When no signal is input to the connected video equipment, the TV screen becomes blue.

#### CAUTION

Do not connect the power cord until you have completed making all other connections; otherwise a minimum leakage current might flow through the antenna and other terminals to ground.

### Step 2

#### Insert the batteries into the remote




#### Note

- Do not use old batteries nor use different types of batteries together.

### Step 3

#### Preset the channels automatically



#### Tips

- If you want to stop automatic channel presetting, press SELECT twice.
- If your TV has preset an unwanted channel or cannot preset a particular channel, then preset your TV manually (see page 9).

#### Note

- During automatic channel presetting, your TV screen will indicate "B/G" or "D/K" for the TV system.

#### Now You Are Ready. . .



To watch your TV, see page 11.




Using Your New TV | 5

## Connecting optional components

You can connect optional video components, such as a VCR, multi disc player, camcorder or video game.

To watch the picture of the connected equipment, press   (see page 12).


### Connecting a camcorder/video game equipment using the (video input) jacks



#### Note

- You can also connect video equipment to the  1 (video input) jacks at the rear of your TV.

### Connecting video equipment using the (monitor output) jacks



#### Note

- When connecting a stereo VCR, connect the yellow plug to  (the yellow jack) and the white plug to  (the black jack).

6 | Using Your New TV


## Securing the TV

To prevent the TV from falling, secure the TV using one of the following methods:

- A** With the supplied screws, attach the band to the TV stand and to the rear of the TV using the provided hole.

or

- B** Put the cord or chain through the clamps to secure the TV against a wall or pillar.




### Note

- Use only the supplied screws. Use of other screws may damage the TV.

Using Your New TV

## Presetting channels

You can preset up to 100 TV channels in numerical sequence from program number 1 using the remote and the buttons on your TV as well.



### Presetting channels automatically

- 1** Press ① to turn on the TV.



- 2** Press AUTO PROGR.








### Note

- During automatic channel presetting, your TV screen will indicate "B/G" or "D/K" for the TV system.

### To preset channels automatically from a specified program number

- Press SELECT until "AUTO PROGRAM" appears.
- Press + or -. The on-screen display will start flashing.
- Press PROGR +/- or the number buttons until the desired program number appears.
- Press + or -.

## Presetting channels manually

- 1 Press SELECT until "MANUAL PROGRAM" appears.
 
- 2 Press + or -.
 
- 3 Press PROGR +/- or the number buttons until the desired program number appears.
 
- 4 Press + or - until the desired channel picture appears.
 
- 5 Press SELECT.
 

## To change the TV system setting

If the picture or sound is abnormal when receiving programs through the ㄥ (antenna) terminal.

- (1) Press SELECT until "TV SYS" appears.

TV SYS: B/G

- (2) Press + or - to select the appropriate TV system until the picture or sound quality is optimal.

B/G → D/K

## Presetting channels (continued)

### To change the color system setting

If the color is abnormal when receiving programs through the ㄥ (antenna) terminal or the ㄣ (video input) jack

- (1) Press SELECT until "COL SYS" appears.

COL SYS : AUTO

- (2) Press + or - to select the appropriate color system until the color is optimal.

AUTO → PAL → SECAM → NTSC 3.58 → NTSC 4.43

#### Tip

- Normally set "COL SYS" to "AUTO".

## Skipping program numbers

- 1 Press PROGR +/- or the number buttons until the unused or unwanted program number appears.
- 2 Press SELECT until "MANUAL PROGRAM" appears.
- 3 Press + or -.
- 4 Press PIC MODE.
- 5 Press SELECT.

## To preset the skipped program number again

Preset the channel automatically or manually.

#### Tip

- You can also use SELECT and ㄠ +/- on the TV to preset channels and skip program numbers.

## To use the fine tuning (FINE) function

The fine tuning (FINE) function may help to reduce the following problems: double images and lines moving across the TV screen.


You can use the fine tuning function as below:

- (1) Select the program number you want to adjust.
- (2) Press SELECT until "MANUAL PROGRAM" appears on the screen.
- (3) Press + or - on the remote control once.
- (4) Press ㄠ ㄡ to display "FINE" on the screen.
- (5) Press + or - continuously until the above problems are minimized. The + or - icon on the screen flashes while tuning.
- (6) Press SELECT to return to normal screen.

continued

## Watching the TV

This section explains functions used while watching the TV. Most operations can be done using the remote.




### 1 Press ① to turn on the TV.

When the TV is in the standby mode (the ① indicator on the TV is lit red), press ① on the remote or PROGR +/- on the TV.



### 2 Press PROGR +/- or the number buttons to select the TV program.

For double digit numbers, press +/-, then the number (e.g., for 25, press +/-, then 2 and 5).



### 3 Press ④ +/- to adjust the volume.



## Watching the TV (continued)

### Additional tasks

To	Do this
Turn off temporarily	Press ①. The ① indicator on the TV lights up red.
Turn off completely	Press ① on the TV.
Mute the sound	Press ⑤.
Watch the video input (VCR, camcorder, etc.)	Press ⑥ to select "VIDEO 1" or "VIDEO 2". To return to the TV program, press ①.
Jump back to the previous channel	Press JUMP.
Display the on-screen information*	Press ⑦.
Adjust the volume of each TV program automatically	Press SELECT repeatedly until "INTELLIGENT VOL" appears, then press + or - to select "ON". To cancel, select "OFF".

\* The picture, sound, and either the program number or video mode are displayed. The on-screen display for the picture and sound information disappears after about 3 seconds.

## Changing the on-screen display language

### 1 Press SELECT until "LANGUAGE / اللغة : ENGLISH" appears on the screen.



### 2 Press + or - to select "عربي" (Arabic).



#### Tip

- You can also use SELECT and ④ +/- on the TV to select the on-screen display language.

continued

Setting the Wake Up timer

- 1

Press until the desired period of time appears.
- WAKE UP TIMER:10M  
After 10 minutes

WAKE UP TIMER:12H00M  
After 12 hours

WAKE UP TIMER:OFF  
No Wake Up timer

- 2

Select the TV program or video mode you want to display when you wake up.
- 3

Press or set the Sleep timer if you want the TV to turn off automatically.

The indicator on the TV lights up orange.

To cancel the Wake Up timer

Press until “WAKE UP TIMER: OFF” appears or turn off the TV’s main power.

- Notes
- The Wake Up timer starts immediately after the on-screen display disappears.
  - If no buttons or controls are pressed for more than two hours after the TV is turned on using the Wake Up timer, the TV automatically goes into the standby mode. To continue watching the TV, press any button or control on the TV or the remote.

Setting the Sleep timer

- Press until the desired period of time appears.

SLEEP TIMER:30M  
After 30 minutes

SLEEP TIMER:60M  
After 60 minutes

SLEEP TIMER:90M  
After 90 minutes

SLEEP TIMER:OFF  
No Sleep Timer


To cancel the Sleep timer

Press until “SLEEP TIMER: OFF” appears or turn the TV off.

Advanced Operations

Customizing the picture and sound


You can customize the picture and sound by selecting the picture and sound modes or by adjusting its settings.



Selecting the picture and sound modes

To select the picture mode


Press PIC MODE repeatedly until you get the desired picture mode.



Select	To
DYNAMIC	receive high contrast pictures.
STANDARD	receive normal contrast pictures.
SOFT	receive mild pictures.

To select the sound mode


Press SOUND MODE repeatedly until you get the desired sound mode.



Select	To
DYNAMIC	listen to dynamic and clear sound that emphasizes the low and high sound.
DRAMA	listen to sound that emphasizes vocals and background music.
SOFT	receive soft sound.

## Adjusting the picture and sound settings

- 1 Press SELECT until the desired setting appears.



Each time you press SELECT, the setting item will change as follows:

- 2 Press + or – to adjust the item.



- 3 To adjust other items, repeat steps 1 to 2.

\* "HUE" can be adjusted for NTSC system only.


### Notes

- When you select a picture or sound mode, the adjusted settings will be reset according to the selected mode.
- You can also use SELECT and  $\triangle$  +/- on the TV to adjust the sound and picture settings.

Advanced Operations


## Viewing your favorite channels

You can display six of your favorite channels for quick and easy selection. You can change the favorite channel setting as well.




### Selecting a favorite channel

- 1 Press FAVORITE.




- 2 Press the number button from 1 to 6 to select the desired channel.



When you use the FAVORITE CH feature for the first time, six preset channels will appear.

### Changing the favorite channel setting


- 1 Press SELECT until "FAVORITE CH SET UP" appears.



- 2 Press + or – to select the favorite channel you want to change (e.g. ③ PR03).



- 3 Press PROG. +/-, or the number buttons to change the program number.




- 4 Repeat steps 2 and 3 to set other favorite channels.

- 5 Press SELECT.


## Blocking the channels (CHILD LOCK)

You can prevent a child from watching certain programs by using the buttons on the remote control.





**1** Select the TV program you want to lock.


**2** Press SELECT until "CHILD LOCK" appears on the screen.



**3** Press + or - to select "ON".

The  symbol appears on the screen.

To unlock the channel, press + or - to select "OFF". The  symbol disappears from the screen.





### Note


- If you preset a locked channel, that particular channel will be unlocked automatically.


## Additional Information


### Self-diagnosis function


Your TV is equipped with a self-diagnosis function. If there is a problem with your TV, the  indicator flashes red. The number of times the  indicator flashes indicates the possible causes.


Front of TV



**1** Check that the  indicator flashes red a number of times between 3-second intervals.









**2** Count the number of times the  indicator flashes.

**3** Press  (main power) to turn off your TV.

**4** Inform your nearest Sony service center about the number of times the  indicator flashes. Be sure to note the model name and serial number located on the rear of your TV.







## Troubleshooting

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer .

Symptom	Solutions	Possible cause
<b>Snowy picture</b> 	<ul style="list-style-type: none"> <li>Check the antenna cable and connection on the TV, VCR and on the wall. (page 4)</li> <li>Press SELECT until "MANUAL PROGRAM" appears on the screen then preset the channel again. (page 9)</li> </ul>	<ul style="list-style-type: none"> <li>Connection is loose or the cable is damaged.</li> <li>Channel presetting is inappropriate or incomplete.</li> </ul>
<b>Noisy sound</b> 	<ul style="list-style-type: none"> <li>Check the antenna type (VHF/UHF). Contact a Sony dealer for advice.</li> <li>Adjust the antenna direction. Contact a Sony dealer for advice.</li> <li>Try using a booster.</li> </ul>	<ul style="list-style-type: none"> <li>The antenna type is inappropriate.</li> <li>The antenna direction is inappropriate.</li> <li>Signal transmission is low.</li> </ul>
<b>Distorted picture</b> 	<ul style="list-style-type: none"> <li>Turn off or disconnect the booster if it is in use.</li> </ul>	<ul style="list-style-type: none"> <li>Broadcast signals are too strong.</li> </ul>
<b>Noisy sound</b> 		
<b>Good picture</b> 	<ul style="list-style-type: none"> <li>If the sound of some channels are noisy, select the channel, then select the appropriate TV system (TV SYS). (page 10)</li> </ul>	<ul style="list-style-type: none"> <li>The TV system setting is inappropriate.</li> </ul>
<b>Noisy sound</b> 		
<b>No picture</b> 	<ul style="list-style-type: none"> <li>Check the power cord, antenna and the VCR connections.</li> <li>Press (power).</li> <li>Press (main power) on the TV to turn off the TV for about five seconds, then turn it on again.</li> </ul>	<ul style="list-style-type: none"> <li>The power cord, antenna or VCR is not connected.</li> <li>The TV is not turned on.</li> </ul>
<b>No sound</b> 		

continued

## Troubleshooting (continued)

Symptom	Solutions	Possible cause
<b>Good picture</b> 	<ul style="list-style-type: none"> <li>Press <math>\triangle</math> + to increase the volume level.</li> <li>Press <math>\times</math> to cancel the muting.</li> </ul>	<ul style="list-style-type: none"> <li>The volume level is too low.</li> <li>The sound is muted.</li> </ul>
<b>No sound</b> 		
<b>Dotted lines or stripes</b> 	<ul style="list-style-type: none"> <li>Do not use a hair dryer or other equipment near the TV.</li> <li>Adjust the antenna direction for minimum interference. Contact a Sony dealer for advice.</li> </ul>	<ul style="list-style-type: none"> <li>There is local interference from cars, neon signs, hair dryers, power generators, etc.</li> </ul>
<b>Double images or "ghosts"</b> 	<ul style="list-style-type: none"> <li>Use a highly directional antenna.</li> <li>Use the fine tuning (FINE) function. (page 10)</li> <li>Adjust the antenna direction. Contact a Sony dealer for advice.</li> <li>Turn off or disconnect the booster if it is in use.</li> </ul>	<ul style="list-style-type: none"> <li>Broadcast signals are reflected by nearby mountains or buildings.</li> <li>The antenna direction is inappropriate.</li> <li>Use of a booster is inappropriate.</li> </ul>
<b>No color</b> 	<ul style="list-style-type: none"> <li>Press SELECT until "COLOR" appears on the screen, then press + or - to adjust the color level. (page 15)</li> <li>Press SELECT until "COL SYS" appears on the screen, then check the color system setting (usually set this to "AUTO"). (page 10).</li> <li>Adjust the antenna direction. Contact a Sony dealer for advice.</li> </ul>	<ul style="list-style-type: none"> <li>The color level setting is too low.</li> <li>The color system setting is inappropriate.</li> <li>The antenna direction is inappropriate.</li> </ul>
<b>Abnormal color patches</b> 	<ul style="list-style-type: none"> <li>Keep external speakers or other electrical equipment away from the TV. Do not move the TV while the TV is turned on. Press (main power) on the TV to turn off the TV for about five minutes, then turn it on again.</li> </ul>	<ul style="list-style-type: none"> <li>The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.</li> </ul>


Additional Information

Symptom	Solutions	Possible cause
Lines moving across the TV screen	<ul style="list-style-type: none"><li>Use the fine tuning (FINE) function. (page 10)</li></ul>	<ul style="list-style-type: none"><li>There is interference from external sources, e.g., heavy machineries, nearby broadcast station.</li></ul>
The indicator on your TV flashes red a number of times between 3-second intervals.	<ul style="list-style-type: none"><li>Contact your nearest Sony service center. (page 18)</li></ul>	<ul style="list-style-type: none"><li>Your TV may need service.</li></ul>
TV cabinet creaks.	—	<ul style="list-style-type: none"><li>Changes in room temperature sometimes make the TV cabinet expand or contract, making a noise. This does not indicate a malfunction.</li></ul>
A "boom" sound is heard when the TV is turned on.	—	<ul style="list-style-type: none"><li>The TV's demagnetizing function is working. This does not indicate a malfunction.</li></ul>

## Identifying parts and controls


Refer to the pages indicated in parentheses ( ) for details.

### Front panel



- 1 ① (main power) button (11)
- 2 PROGR +/- (program) buttons (11)
- 3 +/- (volume) buttons (11)
- 4 TV/video button (12)
- 5 AUTO PROGR (program) button (5)
- 6 SELECT button (10)
- 7 ② (earphone) jack

## Remote Control



- 1 (power) button (11)
- 2 (TV) button (12)
- 3 Number buttons (11)
- 4 JUMP button (12)
- 5 PROGR +/- buttons (11)
- 6 SELECT button (9)
- 7 PIC MODE button (14)
- 8 +/- buttons (8)
- 9 (display) button (12)
- 10 (muting) button (12)
- 11 (video) button (12)
- 12 +/- (volume) buttons (11)
- 13 A/B button  
(not used for KV-2199XDK)
- 14 Timer setting buttons (13)
  - (wake up timer)
  - (sleep timer)
- 15 FAVORITE button (16)


- 16 SOUND MODE button (14)
- 17 Teletext operation buttons  
(not used for KV-2199XDK)
  - (text) (enlarge)
  - (reveal) (hold)
  - (index) (text clear)
  - (FASTEXT: red, green, yellow, blue)

Names/symbols of buttons on the remote are indicated in different colors to represent the available functions.


Label color	Button function
White	For general TV operations
Green	For Teletext operations

## SECTION 2 DISASSEMBLY


### 2-1. REAR COVER REMOVAL



### 2-2. CHASSIS ASSY REMOVAL




### 2-3. F BRACKET REMOVAL



### 2-4. SERVICE POSITION


(Note: Remove F Bracket first.)



## 2-5. REPLACEMENT OF PARTS


For replacement of the Multi Button, cut the welded portions from them, exchange with the new parts, and fix them with screws (+BVTP 3 x 12).

### 2-5-1. REPLACEMENT OF MULTI BUTTON




For replacement of the Light Guide, remove it, and exchange with the new part to fix.


### 2-5-2. REPLACEMENT OF LIGHT GUIDE




### 2-6. TERMINAL BRACKET REMOVAL



### 2-7. DEGAUSS COIL REMOVAL




## 2-8. PICTURE TUBE REMOVAL




## •REMOVAL OF ANODE-CAP

NOTE : After removing the anode, short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT.


## •REMOVING PROCEDURES



- ① Turn up one side of the rubber cap in the direction indicated by the arrow ①.




- ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ②.



- ③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow ③.

## • HOW TO HANDLE AN ANODE-CAP

- ① Do not damage the surface of anode-caps with sharp shaped objects.
- ② Do not press the rubber too hard so as not to damage the inside of anode-cap. A metal fitting called the shatter-hook terminal is built into the rubber.
- ③ Do not turn the foot of rubber over too hard. The shatter-hook terminal will stick out or damage the rubber.



## SECTION 3

### SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switches should be set as follows unless otherwise noted:

PICTURE control ..... normal

BRIGHTNESS control ..... normal

Perform the adjustments in the following order :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

**Note :** Test Equipment Required.

1. Color-bar/Pattern Generator
2. Degausser
3. Oscilloscope

#### Preparation :

- In order to reduce the influence of geomagnetism on the set's picture tube, face it east or west.
- Switch on the set's power and degauss with the degausser.

#### 3-1. BEAM LANDING

1. Input a white signal with the pattern generator.

Contrast } normal  
Brightness }

2. Position neck Assy as shown in Fig3-2.
3. Set the pattern generator raster signal to a green raster.
4. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side.  
(See Figures 3-1 through 3-3.)
5. Move the deflection yoke forward and adjust so that the entire screen is green. (See Figure 3-1.)
6. Switch the raster signal to blue, then to red and verify the condition.
7. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws and DY spacers.
8. If the beam does not land correctly in all the corners, use a magnet to adjust it.  
(See Figure 3-4.)





Fig. 3-1



**Note:**  
Neck Assy is exactly behind  
DY (no gap between Neck  
Assy and DY)

Fig. 3-2




Fig. 3-3





Fig. 3-4

### 3-2. CONVERGENCE


#### Preparation :

- Before starting this adjustment, adjust the focus, horizontal size and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.


#### (1) Horizontal and Vertical Static Convergence




(Moving vertically), adjust the V.STAT magnet so that the red, green and blue dots are on top of each other at the center of the screen.




#### ① V. STAT



#### ② H. STAT VR




#### ③





#### ④ BMC (Hexapole) Magnet.

If the red, green and blue dots are not balanced or aligned, then use the BMC magnet to adjust in the manner described below.



④ Y separation axis correction magnet adjustment.

1. Receive the cross-hatch signal and adjust [PICTURE] to [MIN] and [BRIGHTNESS] to [STANDARD] .
2. Adjust the Y separation axis correction magnet on the neck assembly so that the horizontal lines at the top and bottom of the screen are straight.




**Note**

1. The Red and Blue magnets should be equally far from the horizontal center line.
2. Do not separate the Red and Blue magnets too far. (Less than 8 mm)


**(2) Dynamic Convergence Adjustment**



**Preparation:**

- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence




on DY




**(3) Screen-corner Convergence****3-3. FOCUS ADJUSTMENT**

Adjust FOCUS control on the flyback transformer for the best focus.

**3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS****1. G2 (SCREEN) ADJUSTMENT**


- 1) Set the PICTURE to normal.
- 2) Put to VIDEO input mode without signals.
- 3) Connect R, G and B of the C3 board cathode to the oscilloscope.
- 4) Adjust BRIGHTNESS to obtain the cathode voltage to the value below.
- 5) Adjust G2 (Screen) on FBT until picture shows the point before cut-off.

**2. WHITE BALANCE ADJUSTMENT**

- 1) Set to Service Mode (Refer Section 4-1: ADJUSTMENTS WITH COMMANDER).
- 2) Input white raster signal.
- 3) Set the PICTURE to minimum.
- 4) Select GCT (WHB 4) and BCT (WHB 5) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 5) Set the PICTURE to maximum.
- 6) Select GDR (WHB 1) and BDR (WHB 2) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 7) Write into the memory by pressing [MUTING] then [0].

**3. SUB BRIGHT ADJUSTMENT**

- 1) Set to service mode.
- 2) Input a staircase signal of black to white from the pattern generator.
- 3) BRIGHTNESS .... 50%.  
PICTURE ..... MINIMUM
- 4) Select SBR (WHB7) with [1] and [4], and adjust SBR (WHB7) level with [3] and [6] so that the second stripe from the right is dimly lit.




SECTION 5  
DIAGRAM

KV-2199XDK  
RM-952


KV-2199XDK  
RM-952

KV-2199XDK  
RM-952


5-1. BLOCK DIAGRAM



5-2. FRAME SCHEMATIC DIAGRAM



5-3. CIRCUIT BOARDS LOCATION









## 5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

**Note:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted.
- All electrolytic capacitors are rated at 50V unless otherwise noted.
- All resistors are in ohms.  
 $\text{k}\Omega = 1000\Omega$ ,  $\text{M}\Omega = 1000\text{k}\Omega$
- Indication of resistance which does not have rating electrical power is as follows.


Pitch: 5 mm

Rating electrical power 1/4W (CHIP: 1/10W)


-  : nonflammable resistor.
-  : internal component.
-  : panel designation or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B unless otherwise noted.
- **Readings are taken with a color-bar signal input.**
  - no mark : PAL
  - ( ) : SECAM
  - [ ] : NTSC 3.58
  - « » : NTSC 4.43
- **Readings are taken with a 10 M $\Omega$  digital multimeter.**
- **Voltage are dc with respect to ground unless otherwise noted.**
- **Voltage variations may be noted due to normal production tolerances.**
- **All voltages are in V.**
- \* : Cannot be measured.
- **Circled numbers are waveform references.**
-  : B + bus.
-  : B - bus.
-  : signal path.

**Reference information**


RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: $\times$	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

**Note:** The component identified by shading and mark  are critical for safety. Replace only with part number specified.

## A BOARD WAVEFORMS



(1) Schematic Diagram of A1/2 board




Schematic diagram

← A (1/2) board


Schematic diagram

A (2/2) board →

(2) Schematic Diagram of A2/2 board



A BOARD IC001 CXP86461-622S



**NOTE:**  
The circuit indicated at left contains high voltage of over 600 Vp-p. Please pay attention when inspecting or repairing it to prevent an electric shock.

A BOARD

IC			
IC001	B-10	D004	D-8
IC002	C-9	D005	B-8
IC003	A-9	D006	A-3
IC100	B-5	D203	C-11
IC201	B-11	D300	A-9
IC203	C-3	D301	B-9
IC204	B-2	D302	B-6
IC301	B-6	D303	B-5
IC502	E-6	D304	B-5
IC503	J-5	D305	B-5
IC601	I-8	D306	C-5
IC602	H-6	D307	C-5
IC603	D-8	D308	B-5
IC604	D-10	D309	B-6
IC901	I-13	D310	A-6
PH600	H-7	D311	C-6
		D312	C-6
		D313	A-8
		D315	B-7
		D316	C-7
		D317	B-9
		D314	A-9
		D319	C-6
		D320	C-6
		D321	B-6
		D401	D-2
		D402	C-3
		D403	B-1
		D404	C-2
		D405	C-1
		D406	B-1
		D407	C-2
		D408	C-1
		D409	A-1
		D504	D-5
		D505	H-6
		D506	F-6
		D507	F-6
		D508	I-5
		D509	E-6
		D510	F-5
		D511	F-5
		D512	G-5
		D513	I-5
		D517	F-2
		D518	F-2
		D519	F-2
		D520	E-5
		D521	I-4
		D522	J-4
		D525	F-5
		D526	F-6
		D527	F-3
		D528	F-3
		D529	F-5
		D530	F-2
		D531	E-6
		D532	E-6
		D533	D-2
		D534	E-6
		D600	G-13
		D601	I-8
		D602	G-13
		D603	F-11
		D604	J-7
		D605	G-10
		D606	E-11
		D607	F-10
		D608	E-11
		D609	H-8
		D610	J-8
		D611	I-7
		D612	F-8
		D613	I-7


TRANSISTOR			
Q001	B-8	D004	D-8
Q002	B-8	D005	B-8
Q003	C-9	D006	A-3
Q004	C-9	D203	C-11
Q101	A-4	D300	A-9
Q201	A-11	D301	B-9
Q202	A-11	D302	B-6
Q203	C-11	D303	B-5
Q204	C-11	D304	B-5
Q205	A-12	D305	B-5
Q206	A-11	D306	C-5
Q207	A-11	D307	C-5
Q301	B-8	D308	B-5
Q302	A-6	D309	B-6
Q303	A-6	D310	A-6
Q304	B-6	D311	C-6
Q305	B-5	D312	C-6
Q306	B-5	D313	A-8
Q307	C-7	D315	B-7
Q308	C-7	D316	C-7
Q309	C-7	D317	B-9
Q310	D-7	D314	A-9
Q311	D-9	D319	C-6
Q312	B-7	D320	C-6
Q313	B-8	D321	B-6
Q315	B-5	D401	D-2
Q401	D-2	D402	C-3
Q402	D-1	D403	B-1
Q403	D-2	D404	C-2
Q404	C-3	D405	C-1
Q501	D-6	D406	B-1
Q502	E-7	D407	C-2
Q503	F-6	D408	C-1
Q505	D-6	D409	A-1
Q506	D-2	D504	D-5
Q507	H-6	D505	H-6
Q509	F-6	D506	F-6
Q511	F-1	D507	F-6
Q600	C-12	D508	I-5
Q601	F-11	D509	E-6
Q602	J-7	D510	F-5
Q603	I-7	D511	F-5
Q604	H-6	D512	G-5
Q605	E-12	D513	I-5
Q606	F-11	D517	F-2
Q607	H-13	D518	F-2
Q901	H-13	D519	F-2
Q902	H-13	D520	E-5
		D521	I-4
		D522	J-4
		D525	F-5
		D526	F-6
		D527	F-3
		D528	F-3
		D529	F-5
		D530	F-2
		D531	E-6
		D532	E-6
		D533	D-2
		D534	E-6
		D600	G-13
		D601	I-8
		D602	G-13
		D603	F-11
		D604	J-7
		D605	G-10
		D606	E-11
		D607	F-10
		D608	E-11
		D609	H-8
		D610	J-8
		D611	I-7
		D612	F-8
		D613	I-7

DIODE			
D001	B-8	D004	D-8
D002	C-8	D005	B-8
D003	C-9	D006	A-3

**A** [POWER SUPPLY, HV, MICON, Y/C JUNGLE]



PRINTED WIRING BOARD

– A Board –



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----

A  
—  
B  
—  
C  
—  
D  
—  
D  
—  
E  
—  
F  
—  
G  
—  
H  
—  
I




**VM<sub>1</sub>** [VELOCITY MODULATION]


**C<sub>3</sub>** [RGB OUT]

PRINTED WIRING BOARDS


– VM<sub>1</sub> Board –



– C<sub>3</sub> Board –




C<sub>3</sub> BOARD WAVEFORMS




## 5-5. SEMICONDUCTORS

## DIODE


AK04V0  
AU-01Z-V1  
EL1Z  
GP08D  
RD33EB3T  
RGP02-17EL-6433




D4SB60L




ERC04-06SE  
RN4Z  
RS3F3  
31DQ06-FC5




ERA22-08  
ERD29-08J




DTZ10B  
DTZ-TT11-15B  
RD10S-B  
MA111-TX  
UDZS-TE17-5.1B  
UDZS-TE17-6.8B  
UDZS-TE17-9.1B  
1SS355TE-17




ON3171-R




D1NS4  
RD20ES-B2  
RD30ESB2  
RD39ES-B2  
RD6.8ES-B1  
RD9.1ES-L2  
1SS119-25  
11ES2-NTA2B  
11EQS04




DA204K




5P6M



FMU-G26S




EG010CV0




## LED

SPB-26MVWF




## TRANSISTOR


UN2111  
UN2211  
UN2213  
UN2216  
2SA1162-G  
2SC2712-YG  
2SD2114K




2SA1175-HFE  
2SC2785-HFE




2SA1091-O




2SA1606-E  
2SC4159-E



2SC2458-YGR  
2SD2144S-UVW



2SC2611




2SD774-34




IRF614



2SK2845-LB102



2SD2578-CA




## IC

CXA2139S (48PIN)  
CXP86461-622S (64PIN)  
M24C08-BN6 (8PIN)  
TDA7429S (42PIN)




Dual In-line Package  
Pin 6~98

MM1319AFBE (7PIN)  
NJM2903M (8PIN)




Single In-line Package  
Pin 6~98


NJM78M09FA  
TA7805S




SBX1981-51P



SE-135N




TDA8172



STR-F6654


MARKING SIDE VIEW




Zig-zag In-line Package  
Pin 6~99

RU-1P

MARKING SIDE VIEW



TA8223K



SECTION 6  
EXPLODED VIEW

KV-2199XDK  
RM-952

KV-2199XDK  
RM-952


NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

6-1. CHASSIS

- : BVTP3  $\times$  12 7-685-648-79
- : BVTP4  $\times$  16 7-685-663-71



REF. NO.	PART NO.	DESCRIPTION	REMARK
1	X-4036-416-3	BEZNET ASSY	
2	4-047-464-01	CATCHER, PUSH	
3	4-067-190-01	BUTTON,POWER	
4	4-036-405-11	SPRING, COMPRESSION	
5	4-067-196-01	BUTTON, MULTI	
6	* 4-067-197-01	GUIDE, LIGHT	
7	1-503-902-21	SPEAKER (15X6.5 CM)	
8	4-054-981-01	SCREW, STEP TAPPING	
9	4-365-808-21	SCREW (5), TAPPING	
10	4-046-600-11	SPACER, DY	
11	* 3-704-372-11	HOLDER, HV CABLE	
12	$\triangle$ 8-738-809-05	PICTURE TUBE (A51LPT70X)	
13	8-451-505-11	DEFLECTION YOKE (Y21RSA-S)	
14	* A-1331-884-A	C3 BOARD MOUNTED	
15	4-369-318-61	SPRING, TENSION	
16	$\triangle$ 1-416-946-11	COIL, DEMAGNETIC	
17	* 4-067-189-01	PWB(L), GUIDE	
18	* 4-067-187-01	PWB(R), GUIDE	
19	8-598-449-10	TUNER, FSS BTF-LG433	
20	$\triangle$ 1-453-293-11	TRANSFORMER ASSY, FLYBACK (NX-1748/M3A4)	
21	* A-1299-049-A	A BOARD COMPLETE	
22	4-057-714-01	PIECE ASSY, TLH CORRECTION	
23	4-022-115-00	HOLDER, AC CORD	
24	$\triangle$ 1-574-062-61	CORD, POWER (WITH CONNECTOR) 2.5A/250V	
25	1-452-032-00	MAGNET,DISC	
26	4-051-736-41	PIECE A(90), CONV, CORRECT	
27	* A-1342-453-A	VM1 BOARD MOUNTED	
28	4-067-167-21	BRACKET,TERMINAL	
29	1-452-094-00	CIRCULAR DISC MAGNET B	
30	4-069-651-02	BLOTTING SHEET	
31	* A-1241-355-A	F BOARD MOUNTED	
32	8-453-011-31	NA299-S2	
33	4-064-883-11	HOLDER, DGC	
34	4-067-192-01	DOOR, CONTROL	
35	X-4036-627-1	COVER ASSY, REAR	
36	* 4-069-722-01	CUSHION, F	
37	* 4-069-216-02	CUSHION, SPEAKER	
38	4-067-006-01	LABEL, RUSSIAN (SBN)	
39	4-069-652-02	CUSHION (HS BAND)	

## SECTION 7

### ELECTRICAL PARTS LIST

A

## NOTE:

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
  - All resistors are in ohms
  - F : nonflammable
- CAPACITORS
- MF :  $\mu$ F, PF :  $\mu$ F
- COILS
- MMH : mH, UH :  $\mu$ H

REF.NO.	PART NO.	DESCRIPTION	REMARK			REF.NO.	PART NO.	DESCRIPTION	REMARK		
	* A-1299-049-A	A BOARD COMPLETE *****				C103	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V	
						C104	1-104-665-11	ELECT 100MF	20%	10V	
	1-900-702-13	LEAD ASSY (1CORE),JUMPER				C107	1-163-005-11	CERAMIC CHIP 470PF	10%	50V	
	* 4-055-304-01	HOLDER, LED				C108	1-104-664-11	ELECT 47MF	20%	16V	
	* 4-067-182-03	HOLDER, FBT				C109	1-163-005-11	CERAMIC CHIP 470PF	10%	50V	
	4-382-854-11	SCREW (M3X10), P, SW (+)				C110	1-163-005-11	CERAMIC CHIP 470PF	10%	50V	
	4-382-854-21	SCREW (M3X14), P, SW (+)				C111	1-163-005-11	CERAMIC CHIP 470PF	10%	50V	
						C112	1-104-664-11	ELECT 47MF	20%	16V	
	7-685-648-79	SCREW +BVTP 3X12 TYPE2 IT-3				C113	1-104-664-11	ELECT 47MF	20%	25V	
						C114	1-126-967-11	ELECT 47MF	20%	50V	
		<CAPACITOR>				C202	1-163-020-00	CERAMIC CHIP 0.0082MF	10%	50V	
C003	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C203	1-163-020-00	CERAMIC CHIP 0.0082MF	10%	50V	
C004	1-163-001-11	CERAMIC CHIP 220PF	10%	50V		C204	1-136-159-00	FILM 0.033MF	5%	50V	
C005	1-163-001-11	CERAMIC CHIP 220PF	10%	50V		C205	1-164-161-11	CERAMIC CHIP 0.0022MF	10%	50V	
C006	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V		C206	1-164-161-11	CERAMIC CHIP 0.0022MF	10%	50V	
C007	1-104-664-11	ELECT 47MF	20%	16V		C207	1-136-159-00	FILM 0.033MF	5%	50V	
C008	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C208	1-126-965-11	ELECT 22MF	20%	50V	
C010	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C209	1-126-965-11	ELECT 22MF	20%	50V	
C012	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C210	1-126-933-11	ELECT 100MF	20%	16V	
C013	1-163-021-91	CERAMIC CHIP 0.01MF	10%	50V		C211	1-126-941-11	ELECT 470MF	20%	25V	
C014	1-104-664-11	ELECT 47MF	20%	25V		C212	1-126-933-11	ELECT 100MF	20%	16V	
C015	1-163-009-11	CERAMIC CHIP 0.001MF	10%	50V		C213	1-126-933-11	ELECT 100MF	20%	16V	
C016	1-163-113-00	CERAMIC CHIP 68PF	5%	50V		C214	1-126-942-61	ELECT 1000MF	20%	25V	
C017	1-163-113-00	CERAMIC CHIP 68PF	5%	50V		C215	1-126-942-61	ELECT 1000MF	20%	25V	
C019	1-104-664-11	ELECT 47MF	20%	25V		C216	1-163-021-91	CERAMIC CHIP 0.01MF	10%	50V	
C022	1-163-227-11	CERAMIC CHIP 10PF	0.5PF	50V		C217	1-126-964-11	ELECT 10MF	20%	50V	
C023	1-163-227-11	CERAMIC CHIP 10PF	0.5PF	50V		C218	1-136-167-00	FILM 0.15MF	5%	50V	
C024	1-163-227-11	CERAMIC CHIP 10PF	0.5PF	50V		C219	1-136-167-00	FILM 0.15MF	5%	50V	
C026	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V		C220	1-126-942-61	ELECT 1000MF	20%	25V	
C027	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V		C221	1-126-964-11	ELECT 10MF	20%	50V	
C028	1-163-037-11	CERAMIC CHIP 0.022MF	10%	50V		C223	1-126-965-11	ELECT 22MF	20%	50V	
C030	1-126-965-11	ELECT 22MF	20%	50V		C224	1-163-133-00	CERAMIC CHIP 470PF	5%	50V	
C031	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V		C226	1-109-982-11	CERAMIC CHIP 1MF	10%	10V	
C032	1-107-823-11	CERAMIC CHIP 0.47MF	10%	16V		C227	1-163-037-11	CERAMIC CHIP 0.022MF	10%	50V	
C034	1-163-031-11	CERAMIC CHIP 0.01MF		50V		C228	1-163-024-00	CERAMIC CHIP 0.018MF	10%	50V	
C041	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C229	1-163-018-00	CERAMIC CHIP 0.0056MF	10%	50V	
C042	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C230	1-163-024-00	CERAMIC CHIP 0.018MF	10%	50V	
C043	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C231	1-163-018-00	CERAMIC CHIP 0.0056MF	10%	50V	
C044	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C232	1-163-037-11	CERAMIC CHIP 0.022MF	10%	50V	
C047	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C233	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V	
C048	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C234	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V	
C050	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C235	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V	
C051	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C236	1-164-004-11	CERAMIC CHIP 0.1MF	10%	25V	
C053	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C238	1-164-505-11	CERAMIC CHIP 2.2MF		16V	
C054	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C240	1-164-505-11	CERAMIC CHIP 2.2MF		16V	
C055	1-163-251-11	CERAMIC CHIP 100PF	5%	50V		C241	1-164-346-11	CERAMIC CHIP 1MF		16V	
						C242	1-164-505-11	CERAMIC CHIP 2.2MF		16V	

**A**

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C243	1-216-295-91	SHORT	0	C513	1-163-263-11	CERAMIC CHIP	330PF 5% 50V
C244	1-164-700-11	CERAMIC CHIP	0.68MF 16V	C514	1-106-383-00	MYLAR	0.047MF 10% 200V
C245	1-164-346-11	CERAMIC CHIP	1MF 16V	C517	1-164-182-11	CERAMIC CHIP	0.0033MF 10% 50V
C246	1-163-018-00	CERAMIC CHIP	0.0056MF 10% 50V	C518	1-104-665-11	ELECT	100MF 20% 10V
C248	1-163-010-11	CERAMIC CHIP	0.0012MF 10% 50V	C519	1-102-212-00	CERAMIC	820PF 10% 500V
C249	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C521	1-126-934-11	ELECT	220MF 20% 16V
C251	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V	C522	1-126-933-11	ELECT	100MF 20% 16V
C252	1-164-346-11	CERAMIC CHIP	1MF 16V	C523	1-102-002-00	CERAMIC	680PF 10% 500V
C253	1-163-037-11	CERAMIC CHIP	0.022MF 10% 50V	C524	1-126-967-11	ELECT	47MF 20% 50V
C254	1-126-965-11	ELECT	22MF 20% 50V	C526	1-130-495-00	MYLAR	0.1MF 5% 50V
C255	1-163-037-11	CERAMIC CHIP	0.022MF 10% 50V	C527	1-102-820-00	CERAMIC	330PF 5% 50V
C256	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C528	1-162-134-11	CERAMIC	470PF 10% 2KV
C259	1-126-933-11	ELECT	100MF 20% 16V	C530	1-137-372-11	FILM	0.022MF 5% 50V
C264	1-164-505-11	CERAMIC CHIP	2.2MF 16V	C531	1-126-961-11	ELECT	2.2MF 20% 50V
C265	1-164-505-11	CERAMIC CHIP	2.2MF 16V	C532	1-126-941-11	ELECT	470MF 20% 25V
C301	1-126-935-11	ELECT	470MF 20% 16V	C533	1-126-941-11	ELECT	470MF 20% 25V
C302	1-163-005-11	CERAMIC CHIP	470PF 10% 50V	C536	1-136-165-00	FILM	0.1MF 5% 50V
C303	1-126-964-11	ELECT	10MF 20% 50V	C537	1-126-969-11	ELECT	220MF 20% 50V
C304	1-126-967-11	ELECT	47MF 20% 50V	C538	1-136-076-00	FILM	0.0085MF 3% 2KV
C305	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C539	1-129-746-91	FILM	0.039MF 5% 400V
C306	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	C540	1-136-171-00	FILM	0.33MF 5% 50V
C307	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	C546	1-165-319-11	CERAMIC CHIP	0.1MF 50V
C308	1-163-259-91	CERAMIC CHIP	220PF 5% 50V	C549	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V
C309	1-126-957-11	ELECT	0.22MF 20% 50V	C550	1-106-220-00	MYLAR	0.1MF 10% 100V
C310	1-126-963-11	ELECT	4.7MF 20% 50V	C551	1-126-960-11	ELECT	1MF 20% 50V
C311	1-126-964-11	ELECT	10MF 20% 50V	C552	1-162-116-00	CERAMIC	680PF 10% 2KV
C312	1-164-346-11	CERAMIC CHIP	1MF 16V	C553	1-162-116-00	CERAMIC	680PF 10% 2KV
C313	1-164-346-11	CERAMIC CHIP	1MF 16V	C554	1-137-417-11	MYLAR	0.0047MF 10% 200V
C315	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C556	1-126-941-11	ELECT	470MF 20% 25V
C316	1-104-664-11	ELECT	47MF 20% 25V	C557	1-126-941-11	ELECT	470MF 20% 25V
C317	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C558	1-123-024-21	ELECT	33MF 160V
C318	1-163-031-11	CERAMIC CHIP	0.01MF 50V	C560	1-102-228-00	CERAMIC	470PF 10% 500V
C319	1-163-031-11	CERAMIC CHIP	0.01MF 50V	C561	1-129-708-91	FILM	0.0033MF 5% 630V
C320	1-163-031-11	CERAMIC CHIP	0.01MF 50V	C562	1-102-228-00	CERAMIC	470PF 10% 500V
C322	1-163-005-11	CERAMIC CHIP	470PF 10% 50V	C564	1-163-038-91	CERAMIC CHIP	0.1MF 25V
C324	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V	C565	1-107-655-11	ELECT	47MF 20% 250V
C325	1-126-960-11	ELECT	1MF 20% 50V	C566	1-102-244-00	CERAMIC	220PF 10% 500V
C327	1-126-965-11	ELECT	22MF 20% 50V	C567	1-115-521-11	FILM	0.82MF 5% 250V
C328	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C568	1-102-228-00	CERAMIC	470PF 10% 500V
C330	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C570	1-115-520-11	FILM	0.68MF 5% 250V
C332	1-126-963-11	ELECT	4.7MF 20% 50V	C573	1-106-379-12	MYLAR	0.033MF 10% 200V
C335	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C574	1-107-636-11	ELECT	10MF 20% 160V
C336	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C576	1-130-495-00	MYLAR	0.1MF 5% 50V
C337	1-126-961-11	ELECT	2.2MF 20% 50V	C577	1-106-395-00	MYLAR	0.15MF 10% 200V
C338	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V	C582	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C341	1-115-340-11	CERAMIC CHIP	0.22MF 10% 25V	C586	1-216-295-91	SHORT	0
C342	1-163-259-91	CERAMIC CHIP	220PF 5% 50V	C600 $\Delta$	1-104-705-11	FILM	0.1MF 20% 250V
C402	1-164-346-11	CERAMIC CHIP	1MF 16V	C602 $\Delta$	1-104-705-11	FILM	0.1MF 20% 250V
C404	1-163-005-11	CERAMIC CHIP	470PF 10% 50V	C604	1-163-009-11	CERAMIC CHIP	0.001MF 10% 50V
C405	1-126-935-11	ELECT	470MF 20% 16V	C605 $\Delta$	1-127-942-51	CERAMIC	330PF 10% 250V
C407	1-164-346-11	CERAMIC CHIP	1MF 16V	C606 $\Delta$	1-127-942-51	CERAMIC	330PF 10% 250V
C408	1-163-133-00	CERAMIC CHIP	470PF 5% 50V	C607	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C409	1-126-963-11	ELECT	4.7MF 20% 50V	C608	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C502	1-163-145-00	CERAMIC CHIP	0.0015MF 5% 50V	C609	1-126-968-11	ELECT	100MF 20% 50V
C506	1-107-638-11	ELECT	33MF 20% 160V	C610	1-126-964-11	ELECT	10MF 20% 50V
C507	1-161-830-00	CERAMIC	0.0047MF 500V	C611	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C510	1-102-112-00	CERAMIC	330PF 10% 50V	C612	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C512	1-163-989-11	CERAMIC CHIP	0.033MF 10% 25V	C613	1-117-752-11	ELECT(BLOCK)	330MF 20% 450V



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C614	1-126-964-11	ELECT	10MF 20%	50V	CN604 *	1-573-963-11	PIN, CONNECTOR (PC BOARD) 3P
C616	1-130-202-00	FILM	0.022MF 10%	400V	CN609 *	1-508-784-21	PIN, CONNECTOR (5MM PITCH) 1P
C617	1-107-792-11	CERAMIC	100PF 5%	1KV	CN901 *	1-564-507-11	PLUG, CONNECTOR 4P
C618	1-125-893-11	FILM	680PF 3%	1.5KV			
C619	1-119-886-51	CERAMIC	470PF 10%	250V		<DIODE>	
C620	1-163-133-00	CERAMIC CHIP	470PF 5%	50V			
C621	1-102-114-00	CERAMIC	470PF 10%	50V	D001	8-719-988-61	DIODE 1SS355TE-17
C622	1-102-074-00	CERAMIC	0.001MF 10%	50V	D005	8-719-988-61	DIODE 1SS355TE-17
C623	1-104-665-11	ELECT	100MF 20%	25V	D006	8-719-988-61	DIODE 1SS355TE-17
C624	1-104-331-11	CERAMIC	0.0022MF 10%	1KV	D203	8-719-914-42	DIODE DA204K
C627	1-102-002-00	CERAMIC	680PF 10%	500V	D300	1-216-295-91	SHORT 0
C628	1-126-942-61	ELECT	1000MF 20%	25V	D301	8-719-988-61	DIODE 1SS355TE-17
C629	1-126-964-11	ELECT	10MF 20%	50V	D306	8-719-988-61	DIODE 1SS355TE-17
C630	1-123-024-21	ELECT	33MF	160V	D307	8-719-988-61	DIODE 1SS355TE-17
C633	1-104-999-11	MYLAR	0.1MF 10%	200V	D308	8-719-988-61	DIODE 1SS355TE-17
C634	1-126-933-11	ELECT	100MF 20%	16V	D309	8-719-069-54	DIODE UDZS-TE17-5.1B
C635	1-104-665-11	ELECT	100MF 20%	10V			
C636	1-104-760-11	CERAMIC CHIP	0.047MF 10%	50V	D311	8-719-988-61	DIODE 1SS355TE-17
C639	1-164-004-11	CERAMIC CHIP	0.1MF 10%	25V	D312	8-719-988-61	DIODE 1SS355TE-17
C640	1-164-004-11	CERAMIC CHIP	0.1MF 10%	25V	D313	8-719-988-61	DIODE 1SS355TE-17
C641	1-102-002-00	CERAMIC	680PF 10%	500V	D314	8-719-988-61	DIODE 1SS355TE-17
C642	1-126-943-11	ELECT	2200MF 20%	25V	D315	8-719-988-61	DIODE 1SS355TE-17
C643	1-104-665-11	ELECT	100MF 20%	10V			
C644	1-104-331-11	CERAMIC	0.0022MF 10%	1KV	D316	8-719-069-57	DIODE UDZS-TE17-6.8B
C645	1-137-605-11	FILM	0.01MF 10%	250V	D320	8-719-069-60	DIODE UDZS-TE17-9.1B
C646	1-107-679-91	ELECT	10MF 20%	450V	D321	8-719-069-60	DIODE UDZS-TE17-9.1B
C647	1-163-275-11	CERAMIC CHIP	0.001MF 5%	50V	D402	8-719-069-60	DIODE UDZS-TE17-9.1B
C649	1-126-940-11	ELECT	330MF 20%	25V	D403	8-719-069-60	DIODE UDZS-TE17-9.1B
C650	1-163-275-11	CERAMIC CHIP	0.001MF 5%	50V	D405	8-719-069-60	DIODE UDZS-TE17-9.1B
C651	1-163-133-00	CERAMIC CHIP	470PF 5%	50V	D406	8-719-069-60	DIODE UDZS-TE17-9.1B
C652	1-126-965-11	ELECT	22MF 20%	50V	D504	8-719-302-43	DIODE EL1Z
C653	1-104-664-11	ELECT	47MF 20%	25V	D505	8-719-988-61	DIODE 1SS355TE-17
C657	1-101-821-00	CERAMIC	0.0022MF	500V	D506	8-719-911-19	DIODE 1SS119-25
C658	1-164-004-11	CERAMIC CHIP	0.1MF 10%	25V	D507	8-719-988-61	DIODE 1SS355TE-17
C901	1-136-153-00	FILM	0.01MF 5%	50V	D508	8-719-988-61	DIODE 1SS355TE-17
C902	1-136-153-00	FILM	0.01MF 5%	50V	D509	1-216-073-00	RES,CHIP 10K 5% 1/10W
C905	1-126-963-11	ELECT	4.7MF 20%	50V	D510	8-719-988-61	DIODE 1SS355TE-17
C906	1-164-346-11	CERAMIC CHIP	1MF	16V	D511	8-719-988-61	DIODE 1SS355TE-17
C907	1-163-133-00	CERAMIC CHIP	470PF 5%	50V			
C910	1-126-967-11	ELECT	47MF 20%	50V	D512	8-719-988-61	DIODE 1SS355TE-17
C911	1-126-967-11	ELECT	47MF 20%	50V	D513	8-719-908-03	DIODE GP08D
C912	1-164-004-11	CERAMIC CHIP	0.1MF 10%	25V	D517	8-719-945-80	DIODE ERC06-15S
C913	1-104-665-11	ELECT	100MF 20%	10V	D518	8-719-900-26	DIODE ERD29-08J
C914	1-163-133-00	CERAMIC CHIP	470PF 5%	50V	D521	8-719-302-43	DIODE EL1Z
		<CONNECTOR>			D522	8-719-302-43	DIODE EL1Z
CN104	1-695-915-11	TAB (CONTACT)			D523	8-719-302-43	DIODE EL1Z
CN202 *	1-785-608-11	PIN, CONNECTOR 4P			D527	8-719-908-03	DIODE GP08D
CN203 *	1-564-506-11	PLUG, CONNECTOR 3P			D528	8-719-908-03	DIODE GP08D
CN204 *	1-564-506-11	PLUG, CONNECTOR 3P			D531	8-719-988-61	DIODE 1SS355TE-17
CN305 *	1-564-509-11	PLUG, CONNECTOR 6P					
CN306 *	1-564-510-11	PLUG, CONNECTOR 7P			D532	8-719-988-61	DIODE 1SS355TE-17
CN505	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P			D534	1-216-295-91	SHORT 0
CN506	4-352-844-01	PIN, LEAD, COATING			D602	8-719-911-19	DIODE 1SS119-25
CN601 *	1-580-843-11	PIN, CONNECTOR (POWER)			D603	8-719-150-92	DIODE RD33EB3T
CN602 *	1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P			D604	8-719-028-72	DIODE RGP02-17EL-6433
					D605	8-719-510-53	DIODE D4SB60L
					D606	8-719-108-18	THYRISTOR 5P6M
					D607	8-719-073-01	DIODE MA111-(K8).S0
					D608	8-719-110-53	DIODE RD20ESB2
					D609	8-719-311-31	DIODE RU-1P
					D610	8-719-210-21	DIODE 11EQS04
					D611	8-719-046-74	DIODE AU-01Z-V1



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
D611	8-719-075-73	DIODE 10ELS2N-TB5		IC603	8-759-701-59	IC NJM78M09FA	
D613	8-719-046-74	DIODE AU-01Z-V1		IC604	8-759-231-53	IC TA7805S	
D614	8-719-046-74	DIODE AU-01Z-V1		IC901	8-742-134-00	HYB IC SBX1981-51P	
D618	8-719-067-18	DIODE RN4Z					
D620	8-719-110-72	DIODE RD30ESB2				<JACK>	
D622	8-719-071-39	DIODE FMU-G26S					
D623	8-719-978-65	DIODE DTZ-TT11-15B		J401	1-779-849-11	JACK BLOCK, PIN 4P	
D624	8-719-073-01	DIODE MA111-(K8).S0		J901	1-770-786-21	JACK	
				J902	1-779-205-11	JACK, PIN 2P	
D625	8-719-977-28	DIODE DTZ10B					
D627	8-719-073-84	DIODE 31DQ06-FC5				<CHIP CONDUCTOR>	
D628	8-719-911-19	DIODE 1SS119-25					
D631	8-719-068-00	DIODE ERC04-06SE					
D632	8-719-068-00	DIODE ERC04-06SE		JR001	1-216-295-91	SHORT	0
				JR002	1-216-295-91	SHORT	0
D633	8-719-948-45	DIODE ERA22-08		JR003	1-216-295-91	SHORT	0
D634	8-719-073-01	DIODE MA111-(K8).S0		JR004	1-216-295-91	SHORT	0
D635	8-719-073-01	DIODE MA111-(K8).S0		JR005	1-216-295-91	SHORT	0
D636	8-719-510-02	DIODE D1NS4					
D637	8-719-109-96	DIODE RD6.8ESB1		JR006	1-216-295-91	SHORT	0
				JR007	1-216-295-91	SHORT	0
D638	8-719-024-99	DIODE 11ES2-NTA2B		JR008	1-216-295-91	SHORT	0
D901	8-719-069-60	DIODE UDZS-TE17-9.1B		JR009	1-216-295-91	SHORT	0
D902	8-719-069-60	DIODE UDZS-TE17-9.1B		JR010	1-216-295-91	SHORT	0
D904	8-719-069-60	DIODE UDZS-TE17-9.1B					
D905	8-719-069-60	DIODE UDZS-TE17-9.1B		JR011	1-216-295-91	SHORT	0
				JR012	1-216-295-91	SHORT	0
D906	8-719-045-19	DIODE SPB-26MVWF		JR013	1-216-295-91	SHORT	0
				JR014	1-216-295-91	SHORT	0
				JR015	1-216-295-91	SHORT	0
		<CONNECTOR>					
DY1	* 1-580-798-11	CONNECTOR PIN (DY) 6P		JR016	1-216-295-91	SHORT	0
				JR018	1-216-295-91	SHORT	0
				JR019	1-216-295-91	SHORT	0
				JR102	1-216-295-91	SHORT	0
				JR109	1-216-295-91	SHORT	0
		<FERRITE BEAD>					
FB501	1-410-397-21	FERRITE	1.1UH	JR202	1-216-295-91	SHORT	0
FB502	1-410-397-21	FERRITE	1.1UH	JR301	1-216-295-91	SHORT	0
FB600	1-410-397-21	FERRITE	1.1UH	JR303	1-216-295-91	SHORT	0
FB601	1-410-397-21	FERRITE	1.1UH	JR404	1-216-295-91	SHORT	0
FB602	1-410-397-21	FERRITE	1.1UH	JR405	1-216-295-91	SHORT	0
FB603	1-410-397-21	FERRITE	1.1UH	JR500	1-216-295-91	SHORT	0
FB604	1-412-911-31	FERRITE	0UH	JR501	1-216-295-91	SHORT	0
FB607	1-410-397-21	FERRITE	1.1UH	JR503	1-216-295-91	SHORT	0
FB608	1-412-911-31	FERRITE	0UH	JR600	1-216-295-91	SHORT	0
FB611	1-410-397-21	FERRITE	1.1UH				
FB613	1-410-397-21	FERRITE	1.1UH			<COIL>	
FB615	1-410-397-21	FERRITE	1.1UH				
		<IC>		L002	1-414-856-11	INDUCTOR	10UH
IC001	8-752-906-20	IC CXP86449-622S		L003	1-414-180-11	INDUCTOR	3.3UH
IC002	8-759-371-21	IC MM1319AFBE		L005	1-414-233-22	INDUCTOR CHIP	0UH
IC003	8-759-527-71	IC M24C08-BN6		L101	1-414-856-11	INDUCTOR	10UH
IC201	8-759-336-30	IC TA8223K		L102	1-414-856-11	INDUCTOR	10UH
IC203	8-759-553-40	IC TDA7429S					
				L103	1-414-856-11	INDUCTOR	10UH
IC301	8-752-090-41	IC CXA2139S		L104	1-414-856-11	INDUCTOR	10UH
IC502	8-759-700-07	IC NJM2903M		L105	1-414-856-11	INDUCTOR	10UH
IC503	8-759-980-58	IC TDA8172		L204	1-414-856-11	INDUCTOR	10UH
IC601	8-749-013-75	IC STR-F6654		L301	1-414-189-31	INDUCTOR	100UH
IC602	8-749-920-61	IC SE-135N					
				L302	1-414-185-41	INDUCTOR	22UH
				L501	1-412-525-31	INDUCTOR	10UH
				L502	1-422-613-11	COIL, AIR CORE	
				L503	1-412-525-31	INDUCTOR	10UH
				L504	1-412-525-31	INDUCTOR	10UH

The components identified by shading and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.



REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
L505	1-412-525-31	INDUCTOR	10UH	Q606	8-729-230-49	TRANSISTOR 2SC2712-YG	
L506	1-412-525-31	INDUCTOR	10UH	Q607	8-729-922-37	TRANSISTOR 2SD2144S-UVW	
L507	1-459-111-00	INDUCTOR	10MMH				
L508	1-412-525-31	INDUCTOR	10UH	Q608	8-729-230-49	TRANSISTOR 2SC2712-YG	
L509	1-459-390-00	INDUCTOR	390UH	Q901	8-729-421-19	TRANSISTOR UN2213	
				Q902	8-729-421-19	TRANSISTOR UN2213	
L510	1-416-972-11	COIL, HORIZONTAL LINEARITY					
L512	1-412-549-31	INDUCTOR	1MMH				
L513	1-412-549-31	INDUCTOR	1MMH			<RESISTOR>	
L515	1-459-104-00	COIL, WITH CORE					
L518	1-414-187-11	INDUCTOR	47UH	R001	1-414-233-22	INDUCTOR CHIP	0UH
				R002	1-216-025-91	RES,CHIP	100
L601	1-412-527-11	INDUCTOR	15UH	R003	1-216-295-91	SHORT	0
L901	1-408-603-31	INDUCTOR	10UH	R004	1-216-025-91	RES,CHIP	100
L902	1-408-603-31	INDUCTOR	10UH	R005	1-216-025-91	RES,CHIP	100
L905	1-414-856-11	INDUCTOR	10UH				
				R007	1-216-295-91	SHORT	0
				R008	1-216-065-91	RES,CHIP	4.7K
				R010	1-216-065-91	RES,CHIP	4.7K
				R011	1-216-065-91	RES,CHIP	4.7K
				R012	1-216-065-91	RES,CHIP	4.7K
				R013	1-216-065-91	RES,CHIP	4.7K
				R014	1-216-025-91	RES,CHIP	100
				R015	1-216-025-91	RES,CHIP	100
				R017	1-216-049-91	RES,CHIP	1K
				R018	1-216-033-00	RES,CHIP	220
				R019	1-216-073-00	RES,CHIP	10K
				R021	1-216-073-00	RES,CHIP	10K
				R022	1-216-033-00	RES,CHIP	220
				R024	1-216-057-00	RES,CHIP	2.2K
				R025	1-216-057-00	RES,CHIP	2.2K
				R026	1-216-057-00	RES,CHIP	2.2K
				R027	1-216-073-00	RES,CHIP	10K
				R029	1-216-049-91	RES,CHIP	1K
				R031	1-216-049-91	RES,CHIP	1K
				R035	1-216-025-91	RES,CHIP	100
				R036	1-216-025-91	RES,CHIP	100
				R037	1-216-025-91	RES,CHIP	100
				R040	1-216-025-91	RES,CHIP	100
				R041	1-216-025-91	RES,CHIP	100
				R042	1-216-295-91	SHORT	0
				R043	1-216-049-91	RES,CHIP	1K
				R044	1-216-025-91	RES,CHIP	100
				R045	1-414-233-22	INDUCTOR CHIP	0UH
				R046	1-216-049-91	RES,CHIP	1K
				R047	1-414-233-22	INDUCTOR CHIP	0UH
				R048	1-216-073-00	RES,CHIP	10K
				R050	1-216-073-00	RES,CHIP	10K
				R053	1-216-049-91	RES,CHIP	1K
				R055	1-216-073-00	RES,CHIP	10K
				R056	1-216-073-00	RES,CHIP	10K
				R061	1-216-033-00	RES,CHIP	220
				R062	1-216-041-00	RES,CHIP	470
				R063	1-216-037-00	RES,CHIP	330
				R064	1-216-037-00	RES,CHIP	330
				R065	1-216-037-00	RES,CHIP	330
				R066	1-216-049-91	RES,CHIP	1K
				R067	1-216-049-91	RES,CHIP	1K
				R105	1-216-295-91	SHORT	0
				R109	1-216-041-00	RES,CHIP	470
				R111	1-216-025-91	RES,CHIP	100



REF. NO.	PART NO.	DESCRIPTION	REMARK			
R112	1-216-025-91	RES,CHIP	100	5%	1/10W	
R113	1-216-047-91	RES,CHIP	820	5%	1/10W	
R202	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	
R203	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	
R204	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	
R205	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	
R206	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	
R207	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	
R208	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	
R209	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	
R210	1-216-019-00	RES,CHIP	56	5%	1/10W	
R212	1-216-019-00	RES,CHIP	56	5%	1/10W	
R213	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R214	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R215	1-216-059-00	RES,CHIP	2.7K	5%	1/10W	
R216	1-216-059-00	RES,CHIP	2.7K	5%	1/10W	
R217	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	
R218	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	
R219	1-216-025-91	RES,CHIP	100	5%	1/10W	
R220	1-216-025-91	RES,CHIP	100	5%	1/10W	
R221	1-216-295-91	SHORT	0			
R225	1-216-033-00	RES,CHIP	220	5%	1/10W	
R226	1-216-033-00	RES,CHIP	220	5%	1/10W	
R227	1-216-033-00	RES,CHIP	220	5%	1/10W	
R228	1-249-389-11	CARBON	4.7	5%	1/4W	
R229	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R230	1-216-069-00	RES,CHIP	6.8K	5%	1/10W	
R231	1-216-295-91	SHORT	0			
R234	1-249-389-11	CARBON	4.7	5%	1/4W	
R235	1-216-069-00	RES,CHIP	6.8K	5%	1/10W	
R236	1-216-069-00	RES,CHIP	6.8K	5%	1/10W	
R237	1-216-308-00	RES,CHIP	4.7	5%	1/10W	
R301	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R302	1-216-295-91	SHORT	0			
R303	1-216-049-91	RES,CHIP	1K	5%	1/10W	
R304	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R305	1-216-051-00	RES,CHIP	1.2K	5%	1/10W	
R306	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R308	1-216-025-91	RES,CHIP	100	5%	1/10W	
R309	1-216-025-91	RES,CHIP	100	5%	1/10W	
R310	1-216-025-91	RES,CHIP	100	5%	1/10W	
R311	1-216-017-91	RES,CHIP	47	5%	1/10W	
R312	1-216-041-00	RES,CHIP	470	5%	1/10W	
R313	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	
R314	1-216-045-00	RES,CHIP	680	5%	1/10W	
R316	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	
R317	1-216-077-91	RES,CHIP	15K	5%	1/10W	
R318	1-216-051-00	RES,CHIP	1.2K	5%	1/10W	
R319	1-216-025-91	RES,CHIP	100	5%	1/10W	
R320	1-216-065-91	RES,CHIP	4.7K	5%	1/10W	
R321	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R322	1-216-033-00	RES,CHIP	220	5%	1/10W	
R331	1-216-295-91	SHORT	0			
R332	1-216-033-00	RES,CHIP	220	5%	1/10W	
R333	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R334	1-216-129-00	RES,CHIP	2.2M	5%	1/10W	
R335	1-216-045-00	RES,CHIP	680	5%	1/10W	
R338	1-216-033-00	RES,CHIP	220	5%	1/10W	

REF. NO.	PART NO.	DESCRIPTION	REMARK			
R340	1-216-025-91	RES,CHIP	100	5%	1/10W	
R345	1-216-081-00	RES,CHIP	22K	5%	1/10W	
R348	1-208-806-11	RES,CHIP	10K	0.50%	1/10W	
R349	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R350	1-216-061-00	RES,CHIP	3.3K	5%	1/10W	
R351	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	
R354	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	
R355	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	
R356	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	
R357	1-216-079-00	RES,CHIP	18K	5%	1/10W	
R358	1-216-049-91	RES,CHIP	1K	5%	1/10W	
R359	1-216-033-00	RES,CHIP	220	5%	1/10W	
R360	1-216-033-00	RES,CHIP	220	5%	1/10W	
R361	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R362	1-216-075-00	RES,CHIP	12K	5%	1/10W	
R363	1-216-079-00	RES,CHIP	18K	5%	1/10W	
R364	1-216-295-91	SHORT	0			
R365	1-216-033-00	RES,CHIP	220	5%	1/10W	
R366	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R367	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R370	1-216-033-00	RES,CHIP	220	5%	1/10W	
R376	1-216-081-00	RES,CHIP	22K	5%	1/10W	
R377	1-216-121-91	RES,CHIP	1M	5%	1/10W	
R378	1-216-031-00	RES,CHIP	180	5%	1/10W	
R404	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R405	1-216-049-91	RES,CHIP	1K	5%	1/10W	
R406	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R408	1-216-049-91	RES,CHIP	1K	5%	1/10W	
R411	1-216-113-00	RES,CHIP	470K	5%	1/10W	
R412	1-216-041-00	RES,CHIP	470	5%	1/10W	
R413	1-216-021-00	RES,CHIP	68	5%	1/10W	
R414	1-216-113-00	RES,CHIP	470K	5%	1/10W	
R417	1-216-077-91	RES,CHIP	15K	5%	1/10W	
R418	1-216-113-00	RES,CHIP	470K	5%	1/10W	
R419	1-216-022-00	RES,CHIP	75	5%	1/10W	
R426	1-216-033-00	RES,CHIP	220	5%	1/10W	
R505	1-216-099-00	RES,CHIP	120K	5%	1/10W	
R506	1-216-085-00	RES,CHIP	33K	5%	1/10W	
R507	1-249-389-11	CARBON	4.7	5%	1/4W	F
R508	1-215-910-00	METAL OXIDE	68	5%	3W	F
R509	1-215-911-11	METAL OXIDE	100	5%	3W	F
R510	1-215-885-00	METAL OXIDE	68	5%	2W	F
R511	1-215-911-11	METAL OXIDE	100	5%	3W	F
R516	1-216-081-00	RES,CHIP	22K	5%	1/10W	
R518	1-247-807-31	CARBON	100	5%	1/4W	
R520	1-215-445-00	METAL	10K	1%	1/4W	
R522	1-208-806-11	RES,CHIP	10K	0.50%	1/10W	
R523	1-249-411-11	CARBON	330	5%	1/4W	
R525	1-208-830-11	RES,CHIP	100K	0.50%	1/10W	
R526	1-208-798-11	RES,CHIP	4.7K	0.50%	1/10W	
R527	1-216-001-00	RES,CHIP	10	5%	1/10W	
R528	1-208-814-91	RES,CHIP	22K	0.50%	1/10W	
R529	1-208-766-11	RES,CHIP	220	0.50%	1/10W	
R531	1-247-843-11	CARBON	3.3K	5%	1/4W	
R533	1-249-417-11	CARBON	1K	5%	1/4W	
R534	1-216-361-00	METAL OXIDE	0.22	5%	2W	F
R535	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	
R536	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

A

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R537	1-208-814-91	RES,CHIP	22K 0.50% 1/10W	R620	1-215-915-11	METAL OXIDE	470 5% 3W F
R540	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R622	1-215-908-00	METAL OXIDE	33 5% 3W F
R541	1-216-065-91	RES,CHIP	4.7K 5% 1/10W	R623	1-216-095-00	RES,CHIP	82K 5% 1/10W
R542	1-216-295-91	SHORT	0	R624	1-216-089-91	RES,CHIP	47K 5% 1/10W
R543	1-249-426-11	CARBON	5.6K 5% 1/4W F	R626	1-216-049-91	RES,CHIP	1K 5% 1/10W
R544	1-216-457-00	METAL OXIDE	1.2K 5% 2W F	R627	1-240-251-11	CMT,MELF	6.8 5% 10W
R545	1-216-077-91	RES,CHIP	15K 5% 1/10W	R629	1-247-747-11	CARBON	470 5% 1/2W F
R546	1-216-077-91	RES,CHIP	15K 5% 1/10W	R630	1-249-429-11	CARBON	10K 5% 1/4W F
R547	1-216-085-00	RES,CHIP	33K 5% 1/10W	R631	1-216-089-91	RES,CHIP	47K 5% 1/10W
R549	1-215-451-00	METAL	18K 1% 1/4W	R632	1-202-933-61	FUSIBLE	0.1 10% 1/2W F
R550	1-216-097-91	RES,CHIP	100K 5% 1/10W	R634 $\triangle$	1-218-265-11	METAL	8.2M 5% 1W
R551	1-249-421-11	CARBON	2.2K 5% 1/4W	R635	1-216-492-11	METAL OXIDE	82K 5% 3W F
R552	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R636	1-215-924-00	METAL OXIDE	15K 5% 3W F
R553	1-215-457-00	METAL	33K 1% 1/4W	R637	1-216-492-11	METAL OXIDE	82K 5% 3W F
R554	1-215-457-00	METAL	33K 1% 1/4W	R639	1-216-363-00	METAL OXIDE	0.33 5% 2W F
R556	1-215-437-00	METAL	4.7K 1% 1/4W	R640	1-249-415-11	CARBON	680 5% 1/4W
R558	1-249-421-11	CARBON	2.2K 5% 1/4W	R641	1-216-362-11	METAL OXIDE	0.27 5% 2W F
R559	1-249-429-11	CARBON	10K 5% 1/4W	R642	1-249-419-11	CARBON	1.5K 5% 1/4W
R560	1-216-073-00	RES,CHIP	10K 5% 1/10W	R643	1-247-843-11	CARBON	3.3K 5% 1/4W
R562	1-249-401-11	CARBON	47 5% 1/4W	R644	1-249-419-11	CARBON	1.5K 5% 1/4W
R565	1-216-073-00	RES,CHIP	10K 5% 1/10W	R646	1-215-924-00	METAL OXIDE	15K 5% 3W F
R567	1-216-105-91	RES,CHIP	220K 5% 1/10W	R647	1-249-401-11	CARBON	47 5% 1/4W
R568	1-249-383-11	CARBON	1.5 5% 1/4W F	R648	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R570	1-216-069-00	RES,CHIP	6.8K 5% 1/10W	R649	1-249-417-11	CARBON	1K 5% 1/4W
R571	1-215-437-00	METAL	4.7K 1% 1/4W	R650	1-215-882-00	METAL OXIDE	22 5% 2W F
R573	1-216-089-91	RES,CHIP	47K 5% 1/10W	R652	1-215-900-11	METAL OXIDE	22K 5% 2W F
R577	1-215-913-11	METAL OXIDE	220 5% 3W F	R653	1-215-873-00	METAL OXIDE	4.7K 5% 1W F
R578	1-216-369-00	METAL OXIDE	1 5% 2W F	R657	1-260-127-11	CARBON	220K 5% 1/2W
R579	1-216-097-91	RES,CHIP	100K 5% 1/10W	R659	1-216-049-91	RES,CHIP	1K 5% 1/10W
R580	1-208-830-11	RES,CHIP	100K 0.50% 1/10W	R660	1-216-073-00	RES,CHIP	10K 5% 1/10W
R581	1-208-798-11	RES,CHIP	4.7K 0.50% 1/10W	R661	1-215-873-00	METAL OXIDE	4.7K 5% 1W F
R585	1-249-391-11	CARBON	6.8 5% 1/4W F	R680	1-216-308-00	RES,CHIP	4.7 5% 1/10W
R588	1-215-888-00	METAL OXIDE	220 5% 2W F	R901	1-249-411-11	CARBON	330 5% 1/4W
R589	1-215-888-00	METAL OXIDE	220 5% 2W F	R902	1-249-411-11	CARBON	330 5% 1/4W
R590	1-215-465-00	METAL	68K 1% 1/4W	R903	1-216-022-00	RES,CHIP	75 5% 1/10W
R591	1-260-288-11	CARBON	0.47 5% 1/2W F	R904	1-216-033-00	RES,CHIP	220 5% 1/10W
R593	1-260-288-11	CARBON	0.47 5% 1/2W F	R905	1-216-113-00	RES,CHIP	470K 5% 1/10W
R594	1-260-288-11	CARBON	0.47 5% 1/2W F	R906	1-216-077-91	RES,CHIP	15K 5% 1/10W
R596	1-216-485-11	METAL OXIDE	5.6K 5% 3W F	R909	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R597	1-247-750-11	CARBON	680 5% 1/2W F	R910	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R598	1-249-438-11	CARBON	56K 5% 1/4W	R911	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R599	1-249-389-11	CARBON	4.7 5% 1/4W	R912	1-216-041-00	RES,CHIP	470 5% 1/10W
R600	1-249-438-11	CARBON	56K 5% 1/4W	R913	1-216-049-91	RES,CHIP	1K 5% 1/10W
R601	1-249-418-11	CARBON	1.2K 5% 1/4W F	R914	1-216-055-00	RES,CHIP	1.8K 5% 1/10W
R602	1-249-389-11	CARBON	4.7 5% 1/4W F	R915	1-216-061-00	RES,CHIP	3.3K 5% 1/10W
R603	1-215-485-00	METAL	470K 1% 1/4W	R916	1-216-017-91	RES,CHIP	47 5% 1/10W
R604	1-216-097-91	RES,CHIP	100K 5% 1/10W	R917	1-216-041-00	RES,CHIP	470 5% 1/10W
R607	1-249-425-11	CARBON	4.7K 5% 1/4W	R918	1-216-041-00	RES,CHIP	470 5% 1/10W
R608	1-240-205-91	CARBON	22M 5% 1/2W			<RELAY>	
R609	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	RY601 $\triangle$	1-755-299-11	RELAY	
R610	1-216-073-00	RES,CHIP	10K 5% 1/10W				
R611	1-216-089-91	RES,CHIP	47K 5% 1/10W				
R612	1-216-045-00	RES,CHIP	680 5% 1/10W				
R614	1-216-041-00	RES,CHIP	470 5% 1/10W				
R615	1-216-350-11	METAL OXIDE	1.2 5% 1W F				
R616	1-260-302-51	CARBON	6.8 5% 1/2W F				
R617	1-247-791-91	CARBON	22 5% 1/4W				
R619	1-260-128-11	CARBON	270K 5% 1/2W				



REF. NO.	PART NO.	DESCRIPTION	REMARK
		<SWITCH>	
S502	1-572-707-11	SWITCH, LEVER	
S600	$\Delta$ 1-571-433-21	SWITCH, PUSH (AC POWER)	
S901	1-692-431-21	SWITCH, TACTILE	
S902	1-692-431-21	SWITCH, TACTILE	
S903	1-692-431-21	SWITCH, TACTILE	
S904	1-692-431-21	SWITCH, TACTILE	
S905	1-692-431-21	SWITCH, TACTILE	
S906	1-692-431-21	SWITCH, TACTILE	
S907	1-692-431-21	SWITCH, TACTILE	
		<TRANSFORMER>	
T501	1-437-195-11	TRANSFORMER, HORIZONTAL DRIVE	
T503	$\Delta$ 1-453-293-11	FBT ASSY, NX-1748/M3A4	
T601	1-424-682-11	TRANSFORMER, LINE FILTER	
T603	$\Delta$ 1-433-513-31	TRANSFORMER, CONVERTER (SRT)	
T604	$\Delta$ 1-431-852-11	TRANSFORMER, CONVERTER (SRT)	
		<THERMISTOR>	
THP600	1-810-961-11	THERMISTOR, POSITIVE	
		<TUNER>	
TU101	8-598-449-10	TUNER, FSS BTF-LG433	
		<CRYSTAL>	
X001	1-579-125-11	VIBRATOR, CERAMIC	
X301	1-781-134-21	VIBRATOR, CRYSTAL	
X302	1-781-132-21	VIBRATOR, CRYSTAL	
***** * *****			
	* A-1331-884-A	C3 BOARD MOUNTED	*****
	7-682-948-01	SCREW +PSW 3X8	
		<CAPACITOR>	
C701	1-162-114-00	CERAMIC	0.0047MF 2KV
C702	1-102-074-00	CERAMIC	0.001MF 10% 50V
C703	1-107-651-11	ELECT	4.7MF 20% 250V
C704	1-130-202-00	FILM	0.022MF 5% 400V
C706	1-104-664-11	ELECT	47MF 20% 16V
C708	1-102-114-00	CERAMIC	470PF 10% 50V
C709	1-102-114-00	CERAMIC	470PF 10% 50V
C710	1-102-114-00	CERAMIC	470PF 10% 50V
C712	1-102-116-00	CERAMIC	680PF 10% 50V
C713	1-102-116-00	CERAMIC	680PF 10% 50V
C714	1-102-116-00	CERAMIC	680PF 10% 50V
C716	1-126-933-11	ELECT	100MF 20% 16V
C717	1-101-880-00	CERAMIC	47PF 5% 50V
C736	1-102-114-00	CERAMIC	470PF 10% 50V
C737	1-102-114-00	CERAMIC	470PF 10% 50V

REF. NO.	PART NO.	DESCRIPTION	REMARK
C746	1-102-114-00	CERAMIC 470PF 10% 50V	
		<CONNECTOR>	
CN701	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P	
CN702	1-695-915-11	TAB (CONTACT)	
CN703	* 1-564-509-11	PLUG, CONNECTOR 6P	
CN704	1-695-915-11	TAB (CONTACT)	
		<DIODE>	
D701	8-719-911-19	DIODE 1SS119-25	
D702	8-719-911-19	DIODE 1SS119-25	
D703	8-719-911-19	DIODE 1SS119-25	
D707	8-719-911-19	DIODE 1SS119-25	
D708	8-719-911-19	DIODE 1SS119-25	
D709	8-719-911-19	DIODE 1SS119-25	
D710	8-719-911-19	DIODE 1SS119-25	
D711	8-719-911-19	DIODE 1SS119-25	
D712	8-719-911-19	DIODE 1SS119-25	
D713	8-719-911-19	DIODE 1SS119-25	
D714	8-719-911-19	DIODE 1SS119-25	
D715	8-719-911-19	DIODE 1SS119-25	
D716	8-719-911-19	DIODE 1SS119-25	
D717	8-719-121-26	DIODE RD9.1ESL2	
		<JACK>	
J701	$\Delta$ 1-540-071-22	SOCKET, CRT	
		<COIL>	
L701	1-410-667-31	INDUCTOR 22UH	
L710	1-408-613-31	INDUCTOR 68UH	
L711	1-408-613-31	INDUCTOR 68UH	
L712	1-408-613-31	INDUCTOR 68UH	
		<TRANSISTOR>	
Q704	8-729-326-11	TRANSISTOR 2SC2611	
Q705	8-729-326-11	TRANSISTOR 2SC2611	
Q706	8-729-326-11	TRANSISTOR 2SC2611	
Q707	8-729-200-17	TRANSISTOR 2SA1091-O	
Q708	8-729-200-17	TRANSISTOR 2SA1091-O	
Q709	8-729-200-17	TRANSISTOR 2SA1091-O	
Q710	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q711	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q712	8-729-119-78	TRANSISTOR 2SC2785-HFE	
		<RESISTOR>	
R703	1-249-496-11	CARBON 100K 5% 1/2W	
R705	1-216-380-11	METAL OXIDE 8.2 5% 2W F	
R706	1-215-417-00	METAL 680 1% 1/4W	
R707	1-215-413-00	METAL 470 1% 1/4W	
R708	1-216-379-11	METAL OXIDE 6.8 5% 2W F	
R710	1-215-922-11	METAL OXIDE 6.8K 5% 3W F	
R711	1-247-752-11	CARBON 1K 5% 1/2W	

The components identified by shading  
and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

**C<sub>3</sub>** **F** **VM<sub>1</sub>**

REF. NO.	PART NO.	DESCRIPTION	REMARK			
R712	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F
R713	1-247-752-11	CARBON	1K	5%	1/2W	
R714	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F
R715	1-247-752-11	CARBON	1K	5%	1/2W	
R719	1-215-480-00	METAL	300K	1%	1/4W	
R720	1-249-923-11	CARBON	1K	5%	1/4W	F
R721	1-215-489-00	METAL	680K	1%	1/4W	
R722	1-249-923-11	CARBON	1K	5%	1/4W	F
R723	1-215-479-00	METAL	270K	1%	1/4W	
R724	1-249-923-11	CARBON	1K	5%	1/4W	F
R725	1-249-421-11	CARBON	2.2K	5%	1/4W	
R726	1-249-421-11	CARBON	2.2K	5%	1/4W	
R727	1-249-421-11	CARBON	2.2K	5%	1/4W	
R728	1-249-407-11	CARBON	150	5%	1/4W	
R729	1-249-407-11	CARBON	150	5%	1/4W	
R730	1-249-407-11	CARBON	150	5%	1/4W	
R731	1-249-407-11	CARBON	150	5%	1/4W	
R732	1-249-407-11	CARBON	150	5%	1/4W	
R733	1-249-406-11	CARBON	120	5%	1/4W	
R734	1-247-739-11	CARBON	100	5%	1/2W	
R738	1-247-807-31	CARBON	100	5%	1/4W	
R739	1-247-807-31	CARBON	100	5%	1/4W	
R740	1-247-807-31	CARBON	100	5%	1/4W	
R755	1-249-418-11	CARBON	1.2K	5%	1/4W	
R756	1-249-418-11	CARBON	1.2K	5%	1/4W	
R757	1-249-418-11	CARBON	1.2K	5%	1/4W	
<VARIABLE RESISTOR>						
RV702	1-241-656-11	RES, ADJ, METAL FILM 110M				
***** * *****						
* A-1241-355-A		F BOARD MOUNTED				
*****						
1-533-223-11		CLIP, FUSE				
* 4-374-846-01		COVER, CAPACITOR, CAP TYPE				
<CAPACITOR>						
C654	△ 1-117-703-11	CERAMIC	0.0047MF	99%	250V	
C4602	△ 1-104-708-11	FILM	0.47MF	20%	250V	
<CONNECTOR>						
CN4601*	1-580-843-11	PIN, CONNECTOR (POWER)				
CN4602*	1-580-843-11	PIN, CONNECTOR (POWER)				
CN4603	1-695-915-11	TAB (CONTACT)				
<FUSE>						
F4601	△ 1-532-237-00	FUSE, TIME-LAG (BET) 3.15A/250V				

REF. NO.	PART NO.	DESCRIPTION	REMARK			
<RESISTOR>						
R4601	△ 1-202-719-00	SOLID	1M	10%	1/2W	
<TRANSFORMER>						
T4601	1-424-682-11	TRANSFORMER, LINE FILTER				
T4602	1-424-682-11	TRANSFORMER, LINE FILTER				
<VARISTOR>						
VDR461	1-801-073-31	VARISTOR TNR14V471K660				
***** * *****						
* A-1342-453-A		VM1 BOARD MOUNTED	*****			
4-382-854-11		SCREW (M3X10), P, SW (+)				
<CAPACITOR>						
C5902	1-104-661-91	ELECT	330MF	20%	16V	
C5903	1-161-830-00	CERAMIC	0.0047MF		500V	
C5905	1-126-925-11	ELECT	470MF	20%	10V	
C5906	1-130-491-00	MYLAR	0.047MF	5%	50V	
C5907	1-107-638-11	ELECT	33MF	20%	160V	
C5908	1-106-383-00	MYLAR	0.047MF	10%	200V	
C5909	1-126-933-11	ELECT	100MF	20%	16V	
C5910	1-130-471-00	MYLAR	0.001MF	5%	50V	
C5911	1-107-949-11	ELECT	2.2MF	20%	160V	
C5912	1-104-999-11	MYLAR	0.1MF	10%	200V	
C5913	1-130-471-00	MYLAR	0.001MF	5%	50V	
C5914	1-126-933-11	ELECT	100MF	20%	16V	
C5916	1-130-491-00	MYLAR	0.047MF	5%	50V	
C5917	1-126-925-11	ELECT	470MF	20%	10V	
C5918	1-115-341-51	CERAMIC	120PF	10%	500V	
C5920	1-126-964-11	ELECT	10MF	20%	50V	
C5921	1-101-888-00	CERAMIC	68PF	5%	50V	
<CONNECTOR>						
CN5901*	1-564-510-11	PLUG, CONNECTOR 7P				
CN5904*	1-770-723-11	CONNECTOR, BOARD TO BOARD 8P				
<DIODE>						
D5901	8-719-911-19	DIODE 1SS119-25				
D5902	8-719-110-88	DIODE RD39ESB2				
D5903	8-719-911-19	DIODE 1SS119-25				
D5904	8-719-110-88	DIODE RD39ESB2				
D5905	8-719-911-19	DIODE 1SS119-25				
D5906	1-249-406-11	CARBON	120	5%	1/4W	
D5907	1-249-406-11	CARBON	120	5%	1/4W	

**VM<sub>1</sub>**

REF. NO.	PART NO.	DESCRIPTION	REMARK
<COIL>			
L5901	1-414-187-11	INDUCTOR 47UH	
L5902	1-414-856-11	INDUCTOR 10UH	
<TRANSISTOR>			
Q5901	8-729-230-45	TRANSISTOR 2SC2458-YGR	
Q5902	8-729-809-26	TRANSISTOR 2SA1606-E	
Q5903	8-729-230-45	TRANSISTOR 2SC2458-YGR	
Q5904	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q5905	8-729-230-45	TRANSISTOR 2SC2458-YGR	
Q5906	8-729-809-29	TRANSISTOR 2SC4159-E	
Q5908	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q5909	8-729-119-78	TRANSISTOR 2SC2785-HFE	
<RESISTOR>			
R5901	1-247-815-91	CARBON 220 5% 1/4W	
R5902	1-249-414-11	CARBON 560 5% 1/4W	F
R5903	1-247-735-11	CARBON 47 5% 1/2W	F
R5904	1-249-411-11	CARBON 330 5% 1/4W	
R5905	1-249-417-11	CARBON 1K 5% 1/4W	
R5906	1-249-417-11	CARBON 1K 5% 1/4W	
R5907	1-249-417-11	CARBON 1K 5% 1/4W	
R5908	1-249-383-11	CARBON 1.5 5% 1/4W	F
R5909	1-247-815-91	CARBON 220 5% 1/4W	
R5910	1-249-403-11	CARBON 68 5% 1/4W	
R5911	1-249-439-11	CARBON 68K 5% 1/4W	
R5912	1-249-437-11	CARBON 47K 5% 1/4W	
R5914	1-249-403-11	CARBON 68 5% 1/4W	
R5915	1-249-429-11	CARBON 10K 5% 1/4W	
R5916	1-249-419-11	CARBON 1.5K 5% 1/4W	
R5917	1-249-416-11	CARBON 820 5% 1/4W	
R5918	1-249-429-11	CARBON 10K 5% 1/4W	
R5919	1-249-417-11	CARBON 1K 5% 1/4W	F
R5920	1-249-439-11	CARBON 68K 5% 1/4W	
R5921	1-215-912-11	METAL OXIDE 150 5% 3W	F
R5922	1-249-414-11	CARBON 560 5% 1/4W	
R5923	1-249-383-11	CARBON 1.5 5% 1/4W	F
R5925	1-249-401-11	CARBON 47 5% 1/4W	F
R5929	1-215-880-00	METAL OXIDE 10 5% 2W	F
R5930	1-249-413-11	CARBON 470 5% 1/4W	
R5931	1-249-413-11	CARBON 470 5% 1/4W	
R5932	1-249-413-11	CARBON 470 5% 1/4W	
R5933	1-249-413-11	CARBON 470 5% 1/4W	
R5934	1-249-430-11	CARBON 12K 5% 1/4W	
R5935	1-249-429-11	CARBON 10K 5% 1/4W	

REF. NO.	PART NO.	DESCRIPTION	REMARK
***** * *****			
		MISCELLANEOUS	
		*****	
$\triangle$ 1-416-946-11		COIL, DEMAGNETIC	
1-417-151-21		MATCHING TRANSFORMER, ANTENNA	
1-452-032-00		MAGNET, DISC	
1-501-372-81		ANTENNA, TELESCOPIC	
1-503-902-21		SPEAKER (15X6.5 CM)	
1-569-008-21		ADAPTOR, CONVERSION 2P	
$\triangle$ 1-574-062-61		CORD, POWER (WITH CONNECTOR) 2.5A/250V	
8-451-505-11		DEFLECTION YOKE (Y21RSA-S)	
8-453-011-31		NA299-S2	
$\triangle$ 8-738-809-05		PICTURE TUBE (A51LP70X)	
***** * *****			
		ACCESSORIES AND PACKING MATERIALS	
		*****	
1-417-151-21		MATCHING TRANSFORMER, ANTENNA	
1-569-008-21		ADAPTOR, CONVERSION 2P	
3-701-910-01		SCREW, SPECIAL (DIA. 3.8X20)	
3-867-869-11		MANUAL, INSTRUCTION	
4-392-003-11		BAND, HOLD	
4-392-004-11		CLIP	
* 4-039-372-01		BAG, PROTECTION	
* 4-067-165-01		CUSHION, (LOWER)(ASS'Y)	
* 4-067-166-01		CUSHION (UPPER)(ASS'Y)	
* 4-067-175-02		INDIVIDUAL CARTON	
***** * *****			
		REMOTE COMMANDER	
		*****	
1-418-163-11		REMOTE COMMANDER (RM-952)	
9-939-697-01		BATTERY COVER, REMOTE COMMANDER	